

Manual for AlphaTims' command-line interface

Developed by: *Eugenia Voytik, Sander Willems and Matthias Mann.*

This manual is intended to illustrate the usage of the command-line interface (CLI) of AlphaTims.

Table of contents


About.....	- 1 -
How to use AlphaTims.....	- 2 -
Exporting an HDF5 file.....	- 3 -
Exporting an MGF file.....	- 5 -
Exporting a selection.....	- 6 -
General options	- 8 -

About

[AlphaTims](#) is an open-source Python package that provides fast accession and visualization of unprocessed LC-TIMS-Q-TOF data from [Bruker's timsTOF Pro instruments](#). It indexes the data such that it can easily be sliced along all five dimensions: LC, TIMS, QUADRUPOLE, TOF and DETECTOR. It was developed by the [Mann Labs at the Max Planck Institute of Biochemistry](#) and is available as a freely available open-source tool with an [Apache License](#) and [third-party licenses](#).

How to use the AlphaTims CLI

When AlphaTims is installed in a [conda](#) environment (see on [installation](#) section on GitHub), it always needs to be activated first with `conda activate alphetims`. Once this environment is active (indicated in the command-line by an `(alphetims)` prefix), the command-line interface (CLI) of AlphaTims can be run in a terminal with the command `alphetims`. This will open up the following window:

A terminal window titled 'swillems — zsh — 81x15' showing the output of the 'alphetims' command. The output displays the version 'AlphaTims 0.2.8' and provides usage instructions, options, and available commands.

```
(alphetims) swillems@MaxStrauss ~ alphetims
*****
* AlphaTims 0.2.8 *
*****
Usage: alphetims [OPTIONS] COMMAND [ARGS]...

Options:
  -v, --version  Show the version and exit.
  -h, --help     Show this message and exit.

Commands:
  detect  Detect structures within the data (NotImplemented yet).
  export  Export information.
  gui     Start graphical user interface.
(alphetims) swillems@MaxStrauss ~
```

This main view shows that AlphaTims is correctly installed and able to run, as well as its version.

TROUBLESHOOTING:

- At any point, you can use the `-h` flag to get help about any command. Alternatively, you can try to find an answer in this manual or on the [troubleshooting section](#) of GitHub. If this still does not help, you can open an [issue](#) on GitHub.

AlphaTims provides three different options:

- The command `alphetims gui` will start the graphical user interface (GUI), which has its own [manual](#).
- The command `alphetims detect` currently is unavailable, but will be implemented in the future.
- The third command `alphetims export` allows to export data and is the main focus of this manual. When run, the following output is shown:

```
swillems — -zsh — 81x16
(alphatims) swillems@MaxStrauss ~ alphatims export
*****
* AlphaTims 0.2.8 *
*****
Usage: alphatims export [OPTIONS] COMMAND [ARGS]...

Export information.

Options:
  -h, --help  Show this message and exit.

Commands:
  hdf      Export BRUKER_RAW_DATA as hdf file.
  mgf      Export BRUKER_RAW_DATA as (profile) mgf file.
  selection Load a BRUKER_RAW_DATA and select a data slice for export.
(alphatims) swillems@MaxStrauss ~
```

This provides three different options

- **alphatims export hdf**, to index the raw data and save it as a portable HDF5 file.
- **alphatims export mgf** to create a traditional MGF file with MS2 spectra.
- **alphatims export selection** to export a selection of the data in tabular or graphical format.

Exporting an HDF5 file

The command **alphatims export hdf** has no further subcommands. It does however always require BRUKER_RAW_DATA input. As such, running this bare command provides the following error message:

```
swillems — -zsh — 81x9
(alphatims) swillems@MaxStrauss ~ alphatims export hdf
*****
* AlphaTims 0.2.8 *
*****
Usage: alphatims export hdf [OPTIONS] BRUKER_RAW_DATA
Try 'alphatims export hdf -h' for help.

Error: Missing argument 'BRUKER_RAW_DATA'.
(alphatims) swillems@MaxStrauss ~
```

Instead of running the bare command that is missing required input, you can use a **-h** flag to check out the full options:

```
swillems — -zsh — 81x31
(alphatims) swillems@MaxStrauss ~ alphatims export hdf -h
*****
* AlphaTims 0.2.8 *
*****
Usage: alphatims export hdf [OPTIONS] BRUKER_RAW_DATA

Export BRUKER_RAW_DATA as hdf file.


Options:
--disable_overwrite      Disable overwriting of existing files.
--enable_compression     Enable compression of hdf files. If set, this
                        roughly halves files sizes (on-disk), at the
                        cost of taking 2-10 longer accession times.
-o, --output_folder DIRECTORY A directory for all output (blank means
                        'input_file' root is used).
-l, --log_file PATH       Save all log data to a file (blank means
                        'log_[date].txt' with date format
                        yymmddhhmmss in 'logs' folder of AlphaTims
                        directory). [default: ]
-t, --threads INTEGER    The number of threads to use (0 means all,
                        negative means how many threads to leave
                        available). [default: -1]
-s, --disable_log_stream Disable streaming of log data.
-p, --parameter_file FILE A .json file with (non-required) parameters
                        (blank means default parameters are used).
                        NOTE: Parameters defined herein override all
                        default and given CLI parameters.
-e, --export_parameters FILE Save currently selected parameters to a
                        parameter file.
-h, --help               Show this message and exit.
(alphatims) swillems@MaxStrauss ~
```

The first line states how to use this command correctly: **alphatims export hdf [OPTIONS] BRUKER_RAW_DATA**. There are a few important options that can be provided:

- **--disable_overwrite**: By default, AlphaTims converts the RAW_BRUKER_DATA file to a file with the same name, but with an “.hdf” extension instead. This overwrites any file if it already exists. By setting this flag, you can ensure you do not accidentally overwrite files that you previously created.
- **--enable_compression**: Saving raw data as an HDF5 file take roughly 6 Gb of disk space per billion detector events. By setting this flag, this file is automatically compressed which roughly halves the file size. Do note that saving and loading of decompressed files can be quite slow. Also note the when the provided BRUKER_RAW_DATA is already an HDF5 file, it can be (de)compressed, and that this option thus primarily exists to simplify file transfer and archiving.
- All other options are generic and are described in the “General options” section below.

Exporting an MGF file

This command is very similar to the `alphatims export hdf` command and also requires BRUKER_RAW_DATA input. Running it with a `-h` flag like `alphatims export mgf` gives the following output:



```
(alphatims) swillems@Sanders-MacBook-Pro ~ alphatims export mgf -h
*****
* AlphaTims 0.2.8 *
*****
Usage: alphatims export mgf [OPTIONS] BRUKER_RAW_DATA

  Export BRUKER_RAW_DATA as (profile) mgf file.

Options:
  --keep_n_most_abundant_peaks INTEGER      Keep only the n most abundant peaks of each
                                              spectrum. A value of -1 means to keep all
                                              peaks. [default: -1]
  --centroiding_window INTEGER             The smoothing factor to centroid ddaPASEF
                                              spectra. A value of 0 means no
                                              smoothing/centroiding. [default: 5]
  --disable_overwrite                      Disable overwriting of existing files.
  -o, --output_folder DIRECTORY           A directory for all output (blank means
                                              'input_file' root is used).
  -l, --log_file PATH                     Save all log data to a file (blank means
                                              'log_[date].txt' with date format
                                              yymmddhhmmss in 'logs' folder of AlphaTims
                                              directory). [default: ]
  -t, --threads INTEGER                   The number of threads to use (0 means all,
                                              negative means how many threads to leave
                                              available). [default: -1]
  -s, --disable_log_stream                 Disable streaming of log data.
  -p, --parameter_file FILE                A .json file with (non-required) parameters
                                              (blank means default parameters are used).
                                              NOTE: Parameters defined herein override all
                                              default and given CLI parameters.
  -e, --export_parameters FILE             Save currently selected parameters to a
                                              parameter file.
  -h, --help                               Show this message and exit.
(alphatims) swillems@Sanders-MacBook-Pro ~
```

Similar to exporting HDF5 files, there are a few options available:

- `--keep_n_most_abundant_peaks`: TOF spectra can be quite noisy and contain many peaks. With this command you can ensure that only the most relevant peaks are retained.
- `--centroiding_window`: Minor fluctuations in TOF mean that an ion is detected in a small m/z range around its actual m/z value. This parameter determines how wide this range

can be. Smaller values will result in more fine-grained peaks, which potentially splits the signal from a single ion into two peaks. However, larger values lower the resolution.

- **--disable_overwrite**: By default, AlphaTims converts the RAW_BRUKER_DATA file to a file with the same name, but with an “.mgf” extension instead. This overwrites any file if it already exists. By setting this flag, you can ensure you do not accidentally overwrite files that you previously created.
- All other options are generic and are described in the “General options” section below.

Exporting a selection

The CLI also allows to export data selections with the command **alphatims export selection**. As with the other export commands, this always requires BRUKER_RAW_DATA input. Instead of running the bare command, it is best to use a **-h** flag to check out the full options.

There are several options to export a data selection:

1. Coordinate selection

Coordinates in all dimensions can be selected. For each dimension, a (start, stop) pair is always required. If not provided for a particular dimension, the whole range is always taken.

- **--ion_type**: This parameter accepts “precursors” or “fragments” as options. If both are required, the flag should be repeated, i.e. **--ion_type fragments --ion_type precursors**. The default is set to “fragments”.
- **--rt_bounds**: The retention time coordinates (in minutes). If a pair of negative integers is provided, these are assumed to be frame indices instead of retention time values.
- **--mobility_bounds**: The mobility coordinates (in $1/K_0$). If a pair of negative integers is provided, these are assumed to be scan indices instead of mobility values.
- **--precursor_bounds**: The selected precursors. This is typically used to select individual spectra or DIA window groups. A single value can be provided by giving a consecutive pair. E.g., to select precursor 10 use **--precursor_bounds 10 11**. This has no effect if only precursors are selected.
- **--quad_mz_bounds**: The quadrupole borders. This has no effect if only precursors are selected.
- **--tof_mz_bounds**: The TOF m/z coordinates. If a pair of negative integers is provided, these are assumed to be TOF m/z indices instead of TOF m/z values.

- **--intensity_bounds**: The intensity values to select.

```

*****
* AlphaTims 0.2.8 *
*****
Usage: alphetims export selection [OPTIONS] BRUKER_RAW_DATA

  Load a BRUKER_RAW_DATA and select a data slice for export.

Options:
  --ion_type [fragments|precursors]  The ion type to use. Multiple options can be
                                     selected by repeating the flag. [default:
                                     fragments]
  --rt_bounds FLOAT...               The upper and lower rt bounds (as a pair)
                                     for the data selection in seconds. Negative
                                     values are interpreted as frame indices
                                     instead of rt values. [default: (None,
                                     None)]
  --mobility_bounds FLOAT...         The upper and lower mobility bounds (as a
                                     pair) for the data selection. Negative
                                     values are interpreted as scan indices
                                     instead of mobility values. [default:
                                     (None, None)]
  --precursor_bounds INTEGER...      The upper and lower precursor bounds (as a
                                     pair) for the data selection. [default:
                                     (None, None)]
  --quad_mz_bounds FLOAT...          The upper and lower quad mz bounds (as a
                                     pair) for the data selection. [default:
                                     (None, None)]
  --tof_mz_bounds FLOAT...           The upper and lower TOF mz bounds (as a
                                     pair) for the data selection. Negative
                                     values are interpreted as TOF indices
                                     instead of tof mz values. [default: (None,
                                     None)]
  --intensity_bounds FLOAT...        The upper and lower intensity bounds (as a
                                     pair) for the data selection. [default:
                                     (None, None)]


```

2. Export format

The CLI allows to export a data selection in three different formats with the **--format** parameter.

- CSV: A table with all coordinates. This is the default if no value is provided. A file is always exported with the same name as the input file, but with the extension “_selection.csv”.
- HTML/PNG: A plot with the requested coordinates. A file is always exported with the

same name is the input file, but with the extension “_selection.html” or “_selection.png”. If this option is selected, you can determine the axis with the `--x_axis` or `--y_axis` parameters.




```
swillems — zsh — 81x28
--format [csv|html|png]      The format of the exported selection.
                             Multiple options can be selected by
                             repeating the flag. [default: csv]
--x_axis [rt|mobility|tof_mz] The x-axis of the exported selection in case
                             a plot is returned. [default: tof_mz]
--y_axis [rt|mobility|tof_mz|intensity] The y-axis of the exported selection in case
                             a plot is returned. the 'intensity' option
                             returns a 1d plot, otherwise a heatmap is
                             returned. [default: mobility]
-o, --output_folder DIRECTORY A directory for all output (blank means
                             'input_file' root is used).
-l, --log_file PATH           Save all log data to a file (blank means
                             'log_[date].txt' with date format
                             yymmddhhmmss in 'logs' folder of AlphaTims
                             directory). [default: ]
-t, --threads INTEGER         The number of threads to use (<0 means all,
                             negative means how many threads to leave
                             available). [default: -1]
-s, --disable_log_stream      Disable streaming of log data.
-p, --parameter_file FILE     A .json file with (non-required) parameters
                             (blank means default parameters are used).
                             NOTE: Parameters defined herein override all
                             default and given CLI parameters.
-e, --export_parameters FILE   Save currently selected parameters to a
                             parameter file.
-h, --help                    Show this message and exit.
(alphatims) swillems@MaxStrauss ~
```

General options

Most commands of the CLI come with some general options:

- `-o, --output_folder`: By default, AlphaTims uses the same folder as that of the BRUKER_RAW_DATA. This option allows to redirect the output to another folder.
- `-l, --log_file`: By default, AlphaTims saves all logs in its installation directory. This option allows to redirect the log file to another file and folder.
- `-t, --threads`: By default, AlphaTims uses all but one CPUs of your computer. This option allows to override that. Note that by providing a negative number you can instruct AlphaTims to leave these many threads unused.
- `-s, --disable_log_stream`: If many files are parsed with e.g., a script, the terminal output of AlphaTims can become tedious. You can suppress terminal output with this command.

- **-p, --parameter_file**: Instead of providing manual parameters, a file with (non-required) parameters can also be provided.
- **-e, --export_parameters**: To be able to reuse all used parameters for future commands, the current parameter selection can be exported with this command.
- **-h, --help**: Show a help menu instead of executing the command.



```

-o, --output_folder DIRECTORY  A directory for all output (blank means
                                'input_file' root is used).
-l, --log_file PATH             Save all log data to a file (blank means
                                'log_[date].txt' with date format
                                yymmddhhmmss in 'logs' folder of AlphaTims
                                directory). [default: ]
-t, --threads INTEGER          The number of threads to use (<0 means all,
                                negative means how many threads to leave
                                available). [default: -1]
-s, --disable_log_stream        Disable streaming of log data.
-p, --parameter_file FILE      A .json file with (non-required) parameters
                                (blank means default parameters are used).
                                NOTE: Parameters defined herein override all
                                default and given CLI parameters.
-e, --export_parameters FILE    Save currently selected parameters to a
                                parameter file.
-h, --help                     Show this message and exit.
(alphatims) swillems@MaxStrauss ~

```